S+S REGELTECHNIK

Configuration variants

Room temperature sensors and measuring transducers, on-wall, device series Baldur

The room temperature sensors/measuring transducers serve for temperature measurement (in non-precipitating air), setpoint adjustment, presence detection or as a control panel with push-buttons, switches, potentiometers, status indicators (LED) in residential rooms, workshops, office and business facilities, and in the industrial sector.

Technical details for temperature measuring transducers see chapter "**Temperature sensor active**".

Here is a selection of equipment versions for room temperature sensors Special versions can be custom-made upon request.

DEVICE SERIES

**Baldur 1** (85 x 85 x 27 mm)
Baldur 2 (98 x 98 x 33 mm)

Baldur lying

Baldur 1
without operating elements

Baldur 1
with display

Baldur 1
with display and potentiometer

Baldur 1 with potentiometer,
push-button and LED

Baldur 1 with potentiometer
and rocker switch

Baldur 1 with potentiometer
and push-buttons

Baldur 1 with potentiometer
and LEDs

Baldur 1 with potentiometer
and LEDs

Baldur 1 with potentiometer
and LEDs

THERMASGARD® RTF / RTM

Configuration variants
Room temperature sensors and measuring transducers,
on-wall, device series Baldur

S+S REGELTECHNIK

Baldur 2 without operating elements

Baldur 2 with display

Baldur 2 with display, potentiometer and LEDs

Stufe I
Stufe II
Stufe III
Heizung
Störung

Baldur 2 with LEDs and push-buttons

Anlage 1   Anlage 2
Ein/Aus   Ein/Aus

Betrieb Anl. 1
Betrieb Anl. 2
Störung Anl. 1
Störung Anl. 2

Baldur 2 with LEDs and push-buttons

EIN/AUS Stufe 1   Stufe 2 Stufe 3

Betrieb
Stufe 1
Stufe 2
Stufe 3
Störung

Baldur 2 with potentiometer, turn switch and LEDs

Hand
Auto
Stufe 1
Stufe 2

Baldur 2 with potentiometer, turn switch and LEDs

Baldur 2 with potentiometer, push-buttons, LEDs and rocker switch

Stufe 1 Stufe 2

Stufe 1
Stufe 2
Störung

Baldur 2 with potentiometer, turn switch, LEDs and rocker switch

Hand
Auto
Stufe 1
Stufe 2

Baldur 2 with potentiometer and turn switch

Hand
Auto
Stufe I
Stufe II
Stufe III

Baldur 2 with potentiometer, turn switch, LEDs and push-buttons

Handbetrieb Automatik
Auto

Handbetrieb
Automatik
Störung

Baldur 2 with potentiometer, turn switch, LEDs and push-buttons

Auto

Auto
Stufe 1
Stufe 2
Stufe 3

°C